




**NOTICE!**

The animations do not replace the Installation Instruction. Please refer also to our Technical Documentation („BAL0815-0002“, „MV0815-0005“, „MV0815-0006“ and „MV0815-0007“)!

### SingleFlexLine 0815 Conductor Rail System



Please click the hyperlink or scan the code to start each animation:

SingleFlexLine 0815 Overview:

[MOV0815-0001](#)



Cutting Phased Rail and PE<sub>plus</sub> Rail,  
Notching for PE<sub>plus</sub> Rail:

[MOV0815-0002](#)



Bending Rail:

[MOV0815-0003](#)



Mounting Hanger Clamps  
(clip-in, screwable and turnable):

[MOV0815-0004](#)



Mounting Retaining Plate:

[MOV0815-0005](#)



Mounting End Cap for End Cap Base and  
Clipping Rail:

[MOV0815-0006](#)



Connecting Rails:

[MOV0815-0007](#)



Mounting Anchor Point:

[MOV0815-0008](#)



Using Dismantling Tool:

[MOV0815-0009](#)



Mounting EMS Current Collector on Base  
Plate:

[MOV0815-0010](#)



EMS Current Collector Tolerances:

[MOV0815-0011](#)



Mounting Air Gap Insulation Section:

[MOV0815-0012](#)



Notes:

**Conductix-Wampfler GmbH**  
Rheinstraße 27 + 33  
79576 Weil am Rhein - Märkt  
Germany

Phone: +49 (0) 7621 662-0  
Fax: +49 (0) 7621 662-144  
info.de@conductix.com  
www.conductix.com